



Preparation For Weighing

Tanks

1. Fuel Tank
 - This may contain fuel, access will be required into the tank through the inspection hatch in the tank to check the level.
2. Water Tanks
 - This must be empty and sponged dry, inspection hatches to be removed to allow checking
3. Holding / Toilet Tank
 - This tank must be confirmed as empty and may be checked by opening seacock once boat is lifted above water.

The following note are only a guide based on the Class Rules – In case of discrepancy the Class Rules take precedence.

Measurement Condition C.6.3 (Page 12)

Appendix G (Page 42) Lists Cruising Features which May Be Removed

Appendix H (Page 43) Lists Racing Features which Shall Remain

Deck

Only the running rigging listed in Appendix D is part of the measurement condition, all loose rope, genoa sheets, spinnaker sheets etc shall be removed. – Note 1 Reef Line Required

Bow locker – Windlass (If Fitted) & Gas Bottle may be removed

Aft Lockers – Autopilot (If Fitted) may be removed, Hot water system may be removed

Interior

All interior protection covers & material to be removed for weighing

Up to 3 doors may be removed – Toilet door must remain.

Cushions, Hanging Wardrobes, Saloon Table may be removed

Stove may be removed

Fire Extinguishers & other safety equipment removed